
47
44
46
48
43
42
41
40
43
38
36
16
23
21
29
50
12
27
34
26
32
30
14
25
17
24
22
18
10
20

Figure 1

Figure 2



FIG. - 3


60
BATTERIES +3V
62
DC CONVERTER +5V
64
DC TO DC CONVERTER +12V
66
LIGHT
68
LASER
70
TRANSMITTER
72
CAMERA
74
MONITOR
76
IR ILLUMINATORS
78
GPS

FIG.-4


80
82
HANDHELD SECURITY DEVICE
FLASHCON III
DISPLAY CONSOLE
84
ON/OFF
WEB SITE/SERVER
PROGRAM ALARMS/TIMES
INTRUSION EVENT LOG
SET ALARMS AND INTRUSION ZONES
86
VIDEO
SOUND EFFECT
PHONE/PAGER
EMAIL/FAX
INTRUSION ZONE